
CONCORD AND HOSHO
MODEL 105CONCORD AND HOSHO
MODEL 105

GENERAL INFORMATION

Concord Model 105 and Hosho Model 105 are two speed, dual track tape recorders.

Recordings can be made from a radio, phonograph, TV, magnetic cartridge, and from a crystal or ceramic cartridge.

A remote control switch is provided to start and stop the mechanism when it is being used for dictation.

The two tape speeds are $3\frac{3}{4}$ and $7\frac{1}{2}$ ips. The playing and recording times, using both tracks, are as follows:

Reel Size	$3\frac{3}{4}$ ips	$7\frac{1}{2}$ ips
5" (600 ft.)	1 hour	$\frac{1}{2}$ hour

These recorders are to be connected to an outlet supplying 110-120 volts, 60 cycles AC only. Severe damage will result if connected to a higher voltage or a direct current (DC) line.

Supplied By:

Concord Electronics Corp.
1549 North Vine Street
Hollywood, California

HOWARD W. SAMS & CO., INC. Indianapolis 6, Indiana

The listing of any available replacement part herein does not constitute in any case a recommendation, warranty or guaranty by Howard W. Sams & Co., Inc., as to the quality and suitability of such replacement part. The numbers of these parts have been compiled from information furnished to Howard W. Sams & Co., Inc., by the manufacturers of CQ447



the particular type of replacement part listed. Reproduction or use, without express permission, of editorial or pictorial content, in any manner, is prohibited. No patent liability is assumed with respect to the use of the information contained herein. © 1961 Howard W. Sams & Co., Inc., Indianapolis 6, Indiana. Printed in U.S. of America




FIG.1 TOP VIEW OF MECHANISM WITH DRESS PLATE REMOVED

FUNCTION OF CONTROLS AND JACKS

On-Off-Volume

Turn this knob clockwise to turn the power on to the unit. Further rotation increases the volume during playback. When recording, it controls the recording level.

Selector

1. The tape motion is stopped when the Selector is in the Stop position.
2. Turning the Selector counterclockwise places the unit in Rewind position.
3. Turning the Selector clockwise from Stop position places the unit in play.
4. Turning the Selector clockwise from Play position places the unit in Record.

Fast Forward

Turn Selector to Play position and then pull the Fast Forward lever toward the front of the case to advance the tape rapidly.

Tone Control

Turn this control to the right to increase the treble. This control is operative only when Selector is in Play position.

Speaker Switch

When the switch is in the SP position, the recorder will play back through its built-in speakers. When the switch is in the EP Ext. position, it will play

back through an external speaker or earphones.

Red "R" Button

Press down on the "R" button and turn the Selector to Record to make a recording. This is a safety lock to prevent the recorder from being put into the Record position and erasing a recording.

Speed Change

To change speed from $7\frac{1}{2}$ to $3\frac{3}{4}$ ips, remove head cover (4), knurled capstan screw (93), and lift $7\frac{1}{2}$ ips capstan (94) off and place on capstan holder.

E. P. Jacks

Earphones may be plugged into this jack for monitoring a recording or for listening to the playback of a recording.

"Ext." Output Jack

This jack is provided for playing the recorder through an external speaker, radio, or Hi Fi amplifier.

"Mic" Input Jack

This jack is used when making recordings with the microphone.

"Aux" Radio-Phono Input Jack

This jack is used when recording from a radio, phonograph, or TV.

OPERATING INSTRUCTIONS

Threading the Tape

1. Place a reel of tape on the left hand reel spindle (26).
2. Place an empty reel on the right hand reel spindle (26).
3. Unwind about 15" of tape from the reel. Hold a section taut and insert it in the tape slot. Make sure the dull-coated side faces the rear of the recorder.
4. Insert the free end of the tape into one of the radial slots in the right hand spindle reel. Turn the reel several turns counterclockwise to fasten the tape to the reel and to take up all slack between reels.

Microphone Recording

1. Rotate the On-Off-Volume control clockwise to turn the recorder on. Allow sufficient time for the tubes to warm up.
2. Insert the microphone plug into the "Mic" jack.
3. Set the speed for 3 3/4 or 7 1/2 ips.
4. Turn the Selector to the Record position.
5. Hold the microphone about 6 to 12 inches from your mouth and speak in a normal voice.
6. Adjust the volume control until the record indicator just closes on the loudest passages.

NOTE: Correct volume level on recording is very important. Too weak a signal will result in weak playback and high background noise. Too strong a signal will result in distortion during playback.

Recording from Radio, Phonograph, or TV

Connect the patch cord supplied with the recorder as follows:

1. Connect the alligator clips across the voice coil terminals of the radio, phonograph, or TV.
2. Insert the patch cord plug into the "Aux" jack.
3. Proceed as described under "Microphone Recording".

Cartridge Recording

1. Magnetic Cartridge:
 - (a) Connect the output of the cartridge to a pre-amplifier.
 - (b) Connect the preamplifier output to the "Aux" jack of the recorder.
 - (c) Proceed as described under "Microphone Recording".
2. Crystal or Ceramic Cartridge:
 - (a) Connect the cartridge leads to the "Aux"

jack of the recorder.

- (b) Proceed as described under "Microphone Recording".

Dual-Track Recording

In Dual-Track Recording, only one-half of the tape width is used in making a recording. After the first recording is completed, remove the full reel of tape, turn it over and place on the supply spindle. Thread the tape and proceed with the recording. The tape can be played back in the same manner.

Rewind

To rewind the tape at a rapid speed, turn the Selector to Rewind.

To Play a Recording

1. Thread the tape as described under "Threading the Tape".
2. Turn Selector to the Play position.
3. Adjust the volume to the desired listening level.

To Erase a Recording

Any recording on the tape is automatically erased before a new one is made when in the record position. To erase a recording without putting new material on the tape, follow the normal recording procedure, but set the volume control to the full counterclockwise position.

Fast Forward

Tape can be advanced rapidly by setting the Selector in Play position and then pull the "Fast" forward lever toward the front of the recorder.

Remote Control Switch

The Remote Control Switch plugs into the rear of the recorder. By setting the Selector in Play position, the tape can be started and stopped any time by depressing the button on the Remote Control Switch.

To Edit and Splice Tape

NOTE: It is impossible to edit and splice one track of a two-track tape without affecting the other. Recordings to be edited should be limited to one track tapes.

1. Tape may be edited by cutting out unwanted portions or by joining selection into another sequence. Announcements can be inserted between selections, etc. Unused tape can be spliced for reuse.
2. For best results, cut tape at a slight diagonal, butt ends together and fasten on the glossy side with splicing tape. Trim off any excessive width.

CONCORD AND HOSHO
MODEL 105

FOLDER 5

DISASSEMBLY

To Remove Recorder from Case

1. Remove all accessories from the recorder.
2. Remove all control knobs.
3. Remove head cover (4).
4. Remove the four panel retaining screws.
5. Lift the panel (8) off.

6. Remove four screws from bottom of case.

7. Lift recorder out of case.

8. Unplug the speaker plug from the amplifier chassis.

9. To reassemble, reverse the foregoing procedure.

ADJUSTMENTS

Record-Playback Head

1. Thread a standard frequency tape on the recorder.
2. Adjust the head mounting screws for the angular position that will give maximum output while playing a section of the tape with more than 7,000 cps.
3. Tighten the mounting screws.

3. A force of 1 1/4 to 1 5/8 pounds is required.

4. To obtain this force, bend the metal lug that drive idler tension spring (74) is fastened to.

Drive Idler

1. Fasten a string around the oil cup of drive idler (66).
2. Fasten a spring scale to the string and measure the force necessary to pull drive idler (66) away from the motor pulley (79) and flywheel of capstan (95).

Pressure Roller

To vary the pressure of the pressure roller, pressure roller arm tension spring will have to be adjusted by varying the gap between the coils of the spring. The pressure should be from 2 5/8 to 3 3/8 pounds.

Takeup Torque

The takeup torque is adjusted by varying friction spring (33). It should be adjusted so the upper limit is between 1.3 — 2.1 oz. inches.

CLEANING

The record head, erase head, capstan, pressure roller, and tape guides should be cleaned occasionally to remove the tape residue which is worn off the tape as it passes these parts. Use a soft cloth and alcohol to remove the residue.

Clean the rubber tired idler wheels and belts with cleaning fluid.

LUBRICATION

All rotating parts are provided with oilite bearings and are lubricated before leaving the factory. Under normal use, no lubrication is required for a long period of time. When lubrication is necessary, use sewing machine oil sparingly.

When lubricating the flywheel, remove the capstan screw and inject 4 or 5 drops of sewing oil.

TROUBLE CHART

Symptom	Cause	Remedy
Weak output.	1. Record-playback head (107) not properly aligned.	1. See "Head Adjustment".
	2. Pressure pad (126) not contacting the head properly.	2. If pressure pad is worn, replace. If spring (125) is broken, replace.
	3. Record-playback head (107) defective.	3. Replace.
No takeup reel drive in "Record" or "Play" position.	1. Takeup drive belt (35) broken.	1. Replace.
	2. Brake assembly (44) does not open.	2. Adjust or replace brake assembly (44).
	3. Coupling between takeup drive pulley (34) and takeup hub (30) too loose.	3. Adjust friction disc (32).
	4. Takeup hub (30) or takeup drive pulley (34) does not rotate freely.	4. Lubricate with sewing machine oil.

TROUBLE CHART (CON'T.)

Symptom	Cause	Remedy
Incomplete or no erase.	<ol style="list-style-type: none"> 1. Erase head (124) is not properly aligned. 2. Erase head (124) defective. 3. Defective erase head circuit. 	<ol style="list-style-type: none"> 1. Adjust the erase head. 2. Replace 3. Check circuit components.
Runs slow in fast forward position.	<ol style="list-style-type: none"> 1. Fast forward roller (21), takeup hub (30), or rewind hub (48) dirty. 2. Tape guide posts dirty. 3. Contact between fast forward roller (21) and takeup hub (30) or takeup drive pulley (34) not sufficient. 	<ol style="list-style-type: none"> 1. Remove these parts, clean, lubricate, and reassemble. 2. Clean posts with a soft cloth and alcohol. 3. Clean all contacting surfaces or adjust so they make proper contact.
Wow or Flutter.	<ol style="list-style-type: none"> 1. Play-record head (107), erase head (124), pressure pads (126) and (129), or tape guide post (109) dirty. 2. Motor pulley (79), drive idler wheel (66), capstan flywheel (95), or pressure roller (90) coated with foreign matter. 3. Capstan screw loose. 4. Rotating parts binding. 5. Drive idler wheel (66) or pressure roller (90) has flat spots formed on them. 6. Tape dirty. 	<ol style="list-style-type: none"> 1. Clean these parts with a soft cloth and alcohol. 2. Clean the surface of these parts with a cloth dampened with alcohol. 3. Tighten screw. 4. Clean any binding rotating parts and lubricate 5. Replace drive idler wheel (66) or pressure roller (90). 6. Replace the tape.
Motor (82) will not run.	<ol style="list-style-type: none"> 1. Motor (82) defective. 2. Loose connection. 	<ol style="list-style-type: none"> 1. Replace motor (82). 2. Check motor leads for cold solder joints.
Takeup hub (30) binds in rewind position.	<ol style="list-style-type: none"> 1. Coupling is too close between takeup drive pulley (34) and takeup hub (30). 	<ol style="list-style-type: none"> 1. See "Takeup Torque Adjustment".
No drive in rewind position.	<ol style="list-style-type: none"> 1. Rewind drive belt (49) broken. 2. Spring (120) broken or disconnected. 3. Foreign matter on capstan flywheel (95) and rewind drive pulley (104). 4. Rewind drive pulley (104) or rewind hub (48) binding. 	<ol style="list-style-type: none"> 1. Replace rewind drive belt (49). 2. Replace or reconnect spring (120). 3. Clean with alcohol. 4. Lubricate with sewing machine oil.

CONCORD AND HOSHO
MODEL 105

MECHANICAL PARTS LIST

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1		Head Cover Retainer Screws	13		Fast Forward Slide Retaining Screw
2		Head Cover Retainer Clips	14		Lock Washer
3		Head Cover Retainer	15	A70057	Fast Forward Tension Spring
4	A81125	Head Cover A-L	16	A64951	Fast Forward Slide
5		Fast Forward Knob	17		Belt Guide
6	A87050-A or A87050	Volume Control Knob - K	18		Spacer
7		Volume Control Knob	19	A64957-B	Selector Slide
8	A81029-E	Reel Holders	20		Washer
9		Panel	21	A48093	Fast Forward Roller -L
10	A67448	"C" Washer	22	A85181	Oil Fabric Washer
11	A65199	Fast Forward Roller Shaft	23	A85182	Felt Washer
12	A85181	Oil Case	24		Lockwasher
		Oil Fabric Washer	25		Hex Nut
			26	A67397	Reel Spindle

FOLDER 5





FIG.2A EXPLODED VIEW OF PARTS BELOW DRESS PLATE

**CONCORD AND HOSHIO
MODEL 105**



A PHOTOFAC "EXPLODED" VIEW
©Howard W. Sams & Co., Inc. 1961

FIG.2B EXPLODED VIEW OF PARTS ABOVE BASE PLATE

FOLDER 5

MECHANICAL PARTS LIST (CON'T.)


Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
27	A81055	Ridged Sleeve	93		Capstan Screw
28		Spring Washer	94		7 1/2 Ips Capstan
29		Washer	95	A48059-A	Capstan
30	A81059-B	Take-up Hub	96		Oil Fabric Washer
31	A85151	Friction Felt	97		Capstan Shaft
32	A64887	Friction Disc	98		Lug
33	A70048	Friction Disc and Spring	99		Stiffing Plate
34	A81060	Take-up Drive Pulley	100		Hex Nut
35*	*A83027-B	*Take-up Drive Belt	101		Mounting Bracket
36	A85186	Oil Fabric Washer	102		"C" Washer
37	A67398	Take-up Hub Shaft	103	A85181	Oil Fabric Washer
38		Brake Arm	104	A48090	Rewind Drive Pulley
39		Brake Pad	105	A64955	Rewind Drive Pulley Arm
40	A67396	Stepper	106		Head Assembly Mounting Screw
41	A70073B	Pressure Roller Arm Tension Spring	107	A46017	Record-Playback Head
42		Brake Arm Mounting Screws	108		Record-Playback Head Mtg. Screw
43		Brake Assembly Shaft	109	A67446	Tape Guide Post
44	A64960	Brake Assembly	110	A67449	Tape Guide Post
45		Brake Assembly Tension Spring	111	A64950	Spacer
46	A87051-A	Tone Control Knob-K (Green)	112		Record-Playback and Erase Head
	A87051	Tone Control Knob (Beige)			Mounting Plate
47	A87049-A	Selector Control Knob-K (Green)	113		Lock Washer
	A87049	Selector Control Knob (Beige)	114		Hex Nut
48	A43094	Rewind Hub	115	A64958-B	Pressure Roller Arm
49*	*A83028-B	*Rewind Drive Belt	116		Spacer
50	A67651	Rewind Hub Shaft	117		Pressure Roller Arm Shaft
51		Selector Slide Mounting Screw	118		Screw
52		Lock Washer	119		Plate
53		Washer	120	A70057	Rewind Drive Pulley Arm Tension
54		Fiber Washer			Spring
55		Washer	121		7 1/2 Ips Capstan Storage Post
56		Spacer	122		"C" Washer
57		Selector Lever Mounting Screw	123		Pressure Pad Assembly Shaft
58		Fiber Washer	124	A46017	Erase Head
59	A64792-B	Selector Lever	125		Pressure Pad Tension Spring
60		Lock Washer	126	A85153	Pressure Pad
61		Hex Nut	127		Pressure Pad Tension Spring(Coil)
62		"C" Washer	128		Pressure Pad Arm Shaft
63		Spring Washer	129	A85153	Pressure Pad
64		Felt Washer	130		Pressure Pad Assembly
65		Oil Fabric Washer	131		Pressure Pad Adjusting Screw
66	A67414-B	Drive Idler	132		Pressure Pad Actuating Arm
67		Felt Washer	133		Screw
68		Oil Fabric Washer	134	A64947	Record Lock Button Protector
69		Screw (Hex Hd.)	135		"C" Washer
70		Plate	136	A64794-C	Pressure Roller Arm Hold-out
71		Drive Idler Mounting Plate			Lever
72	A64795-B	Drive Idler Arm	137		Pressure Roller Arm Hold-out
73		Hex Nut			Lever Shaft
74		Drive Idler Tension Spring	138		Spacer
75		Fast Forward Slide Mounting Brkt.	139		Screw
76		Screw	140		Rewind Belt Guide
77		Lock Washer	141		Selector Lever Pivot
78		Baseplate	142		Washer
79		Motor Pulley	143	A81069-B	Record Lock Button
80		Motor Mounting Screws	144	A67463	Selector Cam
81		Lock Washer	145		Set Screw
82	A48055	Motor	146		Record Lock
83		Motor Fan	147		Screw
84		Fan Set Screw	148		Switch Cam Selector Mounting Brkt.
85		Drive Idler Arm Shaft	149		Switch Lever Tension Spring
86		Hex Nut	150		Switch Cam Selector
87		"C" Washer	151		Set Screw
88		Spring Washer	152		Spacer
89		Oil Fabric Washer	153		Tension Spring
90	A48031-B	Pressure Roller	154		Spacer
91		Oil Fabric Washer	155		Switch Lever
92		Washer	156		Set Screw

MECHANICAL PARTS LIST (CON'T.)


Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
157		Switch Lever Shaft	160		Detent Lever
158		Fiber Washer	161		Function Selector Shaft
159		Detent Lever Shaft			

* Rewind Drive Belt
Walsco Part No. 1410-10

* Take-up Drive Belt
Walsco Part No. 1474



AMP CHASSIS-SIDE VIEW



AMP CHASSIS-TOP VIEW

CONCORD AND HOSHO
MODEL 105

FOLDER 5

ELECT. PARTS LIST AND DESCRIPTIONS

PAGE 10

TUBES

• GENERAL ELECTRIC • RAYTHEON • SYLVANIA •			
ITEM No.	USE	TYPE	TYPE
V1	Preamplifier	6AU6	6AV6
V2	AF Amplifier	6AU6	6ME10
V3	Output-Bias Oscillator	50C5	35W4

ELECTROLYTIC CAPACITORS

REPLACEMENT DATA					
ITEM No.	RATING	CONCORD PART No.	AEROVOX PART No.	CORNELL-DUBILIER PART No.	NOTES
C1A	60 CAP. 150	A25103	SRE150V5	FP311.6	
C1B	40 150		NLW5-150	TC40	
C2	5 150		NLW5-150	TC40	TE-1504
C3	5 150		NLW20-15	TC115X20	TE-1504
C4	20 10		PTT10020	TC115X20	TE-1330
C5	20 10		PTT10020	TC115X20	TE-1330
C6	25 25		PTT25025	TC115X20	TE-1207

FIXED CAPACITORS


Capacity values given in the rating column are in mfd. for Paper Capacitors, and in mmfd. for Mica and Ceramic Capacitors.

REPLACEMENT DATA					
ITEM No.	RATING	REMARKS	AEROVOX PART No.	CORNELL-DUBILIER PART No.	SPRAGUE PART No.
C7	.1 400V		P488N-1	CUBAP1	4TM-P10
C8	100 10%		1469-0001	DF-104	MS-31
C9	.022 400V		P488N-022	TC2-100	4TM-S22
C10	.01 400V		P488N-01	DD-203	4TM-S10
C11	.01 400V		P488N-01	D6-103	4TM-S10
C12	.047 400V		P488N-047	DD-503	4TM-S47
C13	330 10%		1469-00033	DD-503	MS-333
C14	100 10%		1469-0001	TC2-100	MS-31
C15	.01 400V		P488N-01	D6-103	4TM-S10
C16	10000 5%		P488N-01	DF-104	MS-11
C17	.1 400V		P488N-1	CUBAP1	4TM-P10
C18	50-300		P488N-01	D6-103	4TM-S10
C19	.01 400V		P488N-01	D6-103	4TM-S10
C20	.01 400V		P488N-01	D6-103	4TM-S10
C21	3300 10%		1469-00033	IRSD33	MS-233
C22	1000 5%		1469-0001	5RSD33	MS-21
C23	.01 400V		P488N-01	D6-104	4TM-S10
C24	.01 400V		P488N-01	D6-104	4TM-S10

CONTROLS

REPLACEMENT DATA				
ITEM No.	RATING	CONCORD PART No.	CENTRALAB PART No.	INSTALLATION NOTES
R1A	500K	A36501		Volume Power Off-On
R1B	Switch			Tone
R2	20K	A36016		

AMP CHASSIS—BOTTOM VIEW



ELECT. PARTS LIST AND DESCRIPTIONS (Continued)

RESISTORS

All wattages 1/2 watt, or less, unless otherwise listed.

ITEM No.	RATING	REPLACEMENT DATA			ITEM No.	RATING	REPLACEMENT DATA		
		IRC PART No.	WORKMAN TV PART No.	REMARKS			IRC PART No.	WORKMAN TV PART No.	REMARKS
R3	470K				R15	3300Ω 2W			
R4	100K 2W				R16	180Ω 2W			
R5	270K 2W				R17	56K			
R6	1200Ω				R18	220K			
R7	10K 1W				R19	5Ω 1W			
R8	100K 2W				R20	4.7meg			
R9	270K 2W				R21	270K			
R10	1200Ω				R22	1meg			
R11	220Ω				R23	7meg			
R12	8200Ω				R24	1meg			
R13	1200Ω				R25	150Ω 2W			
R14	470K								

COILS (RF-IF)

ITEM No.	USE	REPLACEMENT DATA				NOTES
		CONCORD PART No.	Merit PART No.	Miller PART No.	Stancor PART No.	
L1	Oscillator					

TRANSFORMER (POWER)

ITEM No.	RATING			REPLACEMENT DATA					NOTES
	PRI	SEC. 1	SEC. 2	CONCORD PART No.	Merit PART No.	Stancor PART No.	Thordarson PART No.	Triad PART No.	
T1	117V @ .27A Tap @ 100V (Not Used Tap @ 85V @ .150A)	120V @ .040A DC	6.3VCT @ 1.8A	A11013					

TRANSFORMER (AUDIO OUTPUT)

ITEM No.	IMPEDANCE		REPLACEMENT DATA					NOTES
	PRI.	SEC.	CONCORD PART No.	Merit PART No.	Stancor PART No.	Thordarson PART No.	Triad PART No.	
T2	2500Ω	4-5Ω	A12136	A-3025 ①	A-3332 ①	26S58 ①	S-IX ①	① Drill New Mounting Hole (s).

SPEAKER

ITEM No.	TYPE			REPLACEMENT DATA		NOTES
	SIZE	FIELD	V. C. IMP.	CONCORD PART No.	QUAM PART No.	
SP1	3 1/2"	PM	8-10Ω	A45192	3A07Z8	
SP2	3 1/2"	PM	8-10Ω	A45192	3A07Z8	

FUSES

ITEM No.	TYPE	RATING	REPLACEMENT DATA					
			CONCORD PART No.		LITTELFUSE PART No.		BUSS PART No.	
			FUSE	HOLDER	FUSE	HOLDER	FUSE	HOLDER
M1	3AG	1/2 A 250V			312005 (3AG 1 1/2 A 250V)	357001	AGC 1/2	4405

MISCELLANEOUS

ITEM No.	PART NAME	CONCORD PART No.	NOTES
M2	Head	A46017	Record-Playback
M3	Head	A46018	Erase
M4	Switch	A42519	Selector (Slide Type)
M5	Switch	A42200	Speaker (DPDT Slide Type)
M6	Switch	A42518	Speaker (Leaf Type)
M7	Switch	A42517-B	Motor (Leaf Type)
	Motor	A48055	Drive

CABINETS & CABINET PARTS

(When Ordering Cabinets & Cabinet Parts, Specify Model, Chassis & Color)

NAME	PART NO.	DESCRIPTION
Knob	A87050A	Volume, Model 105K
Knob	A87050	Volume, Model 105L
Knob	A87049A	Selector, Green, Model 105K
Knob	A87049	Selector, Beige, Model 105L
Knob	A87051A	Tone, Green, Model 105K
Knob	A87051	Tone, Beige, Model 105L
Knob	A87027B	Fast Forward
Pushbutton	A81069B	Record
Cabinet	A84053B	Green, Model 105K
Cabinet	A84053C	Beige, Model 105L

WIRING DATA

General-use Unshielded Hook-up Wire	Use BELDEN No. 8530 (Solid) Available in Ten Colors
Power Cord	8524 (Stranded) Available in Ten Colors
Low-Loss Shielded Lead (Interconnecting)	1765-B (6 Ft. Length)
Phono Pick-up Arm Cable	1725-K (7 1/2 Ft. Length)
	Use BELDEN No. 8401
	Use BELDEN No. 8430 (Two Conductor - Twisted)

